






# To Start the Hob

---

1. Press the  button  
Do NOT Press the  button.
2. Press the preferred jets  button.
3. Press the  button to increase temperature

To turn off, press the  button